Lab #4: Optical Flow

Course: Computer Vision (CCE5205) – Lecturer: Dr. Reuben Farrugia

The aim of this laboratory session is to implement and analyse the performance of the Horn and Schunck optical flow method [1]. Download the Data/ folder from the VLE. This folder contains a video file named vtest.avi that will be used in this evaluation.

Question 1: Use the opency library to read the first two frames from the video and display them next to each other using the matlibplot library.




Figure 1: First two frames of the video.

Question 2: Write a function that computes the gradients f_x , f_y and f_t . Compute these gradients when considering the first two frames.




Figure 2: Computed gradients.

Question 3: Write a function that can be used to estimate the flow vectors **u** and **v** using the Horn and Schunck method [1].




Figure 3: Flow vectors when considering the first two frames.

Question 4: Use the following script to visualize the flow when considering only the first two frames of the video. Explain what this script is doing and comment on the result.

```
mag, ang = cv2.cartToPolar(U,V)
hsv[...,0] = ang*180/np.pi/2
hsv[...,1] = 255
hsv[...,2] = cv2.normalize(mag,None,0,255,cv2.NORM_MINMAX)
rgb = cv2.cvtColor(hsv,cv2.COLOR_HSV2BGR)
```




Figure 4: Visualization of the flow vector for the first two frames.

Question 5: Use the developed script to compute the flow of the first 100 frames of the video.

References

[1] B. K. Horn and B. G. Schunck, "Determining optical flow," tech. rep., USA, 1980.